

Die Belegung der Funktionstasten des Tischtelefons wird in KIS über den Index festgelegt. In den folgenden Grafiken sehen Sie mit welchem Index welche Taste belegt werden kann.

### Yealink T48



1	13	19	25	7
2	14	20	26	8
3	15	21	27	9
4	16	22	28	10
5	17	23	29	11
6	18	24	30	12

### Yealink T46

Tastenbelegung in KIS

1	10	19
2	11	20
3	12	21
4	13	22
5	14	23



Tastenbelegung in KIS

6	15	24
7	16	25
8	17	26
9	18	27
10 / -	-	-

### Snom D785



Tastenbelegung in KIS

1	7	13	19
2	8	14	20
3	9	15	21
4	10	16	22
5	11	17	23
6	12	18	24

### Snom D385



Tastenbelegung in KIS

7	19	31	43
8	20	32	44
9	21	33	45
10	22	34	46
11	23	35	47
12	24	36	48

1	2	3	4	5	6
13	14	15	16	17	18
25	26	27	28	29	30
37	38	39	40	41	42

Tastenbelegung in KIS